

N E O V O L T A™

Prior to turning on the inverters:

1. Verify the wiring
2. Check that there are no tones
 - a. Tone means there's a short
3. Conduct a continuity test with a voltage meter
4. Turn each battery on, one by one
5. Don't turn the inverter on yet
6. Verify there is no tone between:
 - a. L1 to neutral
 - b. L2 to neutral
 - c. L1 to L2

NEOVOLTA™

Parallel Systems Configuration

Parallel systems REQUIRE 2+ inverters.

If you only have ONE inverter, please keep the inverter OUT of parallel.

For Parallel System:

1. Turn on one inverter (the Master) with the batteries.
2. Do not connect to the grid yet.
3. Do not connect to solar yet.
4. Program the Master inverter, the last step will be parallel on the Master AFTER programming parallel on the slave.

NEOVOLTATM

LCD Settings


- On the Master, select the gear icon



NEOVOLTA™

LCD Settings


- Start with Battery Setting



NEOVOLTA™

LCD Settings


- Select Lithium
- For NV14 or NVPlus Single inverter program:
 - Max A Charge 100A
 - Max A Discharge 150A
- For Parallel inverters program:
 - Max A Charge 185A
 - Max A Discharge 185A
- Checkmark Activate Battery
- To save the settings, press the checkmark



NEOVOLTA™

LCD Settings

- To return to Battery Setting after saving
- Select the gear icon->Battery Setting
- Scroll down to the next page, using the down arrow
- It will show Batt Set2
- This page is the same configuration for single or parallel inverters.
 - Start 30% 20%
 - A 40A 10A
- If there is no generator, leave Gen Charge, Gen Signal and Gen Force de-selected
- Select Grid Charge
- Select Grid Signal
- To save the settings, press the checkmark



NEOVOLTA™

LCD Settings


- To return to Battery Setting after saving
- Select the gear icon->Battery Setting
- Scroll down to the third page, using the down arrow
- It will show Batt Set3
- This page is the same configuration for single or parallel inverters.
 - Lithium Mode 00 – for NV7600 (Lithium Mode 01 – for NV14)
 - Shutdown 10%
 - Low Batt 20%
 - Restart 22%
- To save the settings, press the checkmark



NEOVOLTA™

LCD Settings

- Select the gear icon
- Select System Work Mode



NEOVOLTA™


LCD Settings

- This page is the same configuration for single or parallel inverters.
- NO CTs - set to Zero Export to Load
- CTs- set to Zero Export to CT
- Checkmark Solar Sell
- Energy pattern:
 - Load First

Batt First: PV power is firstly used to charge the battery and then used to power the load. If PV power is insufficient, grid will make supplement for battery and load simultaneously.

Load First: PV power is firstly used to power the load and then used to charge the battery. If PV power is insufficient, grid will make supplement for battery and load simultaneously.

- To save the settings, press the checkmark



NEOVOLTA™

LCD Settings

- To return to System Work Mode after saving
- Select the gear icon->System Work Mode
- Scroll down to the next page, using the down arrow
- It will show WorkMode2



NEOVOLTA™

LCD Settings


- This page is the same configuration for single or parallel inverters.
 - Select Time of Use
 - Select Grid Charge, 01:00-05:00 30%
 - Select Grid Charge, 05:00-08:00 30%
 - 08:00-12:00 100%
 - 12:00-16:00 100%
 - Select Grid Charge, 16:00-21:00 30%
 - Select Grid Charge, 21:00-01:00 30%
- To save the settings, press the checkmark



NEOVOLTA™

LCD Settings


- To return to System Work Mode after saving
- Select the gear icon->System Work Mode
- Scroll down to the next page, using the down arrow
- It will show WorkMode4
- This page is the same configuration for single or parallel inverters.
- Either select all the days or deselect all the days.
- To save the settings, press the checkmark



NEOVOLTA™

LCD Settings

- Select the gear icon
- Select Grid Setting



NEOVOLTA™

LCD Settings


- This page is the same configuration for single or parallel inverters.
 - Grid Mode: CPUC RULE21
 - For USA, Grid Frequency 60Hz
 - Grid Type:
 - If using 240V, select 120/240V Split Phase
 - If using 208V, select 120/208V 3 Phase
- To save the settings, press the checkmark



NEOVOLTA™

LCD Settings


- For AC Solar or Programming a Generator
- Select Gen Port Use



NEOVOLTA™

LCD Settings


- This page is the same configuration for single or parallel inverters.
- For Programming a Generator
 - Select Generator Input
 - Enter 7600W
- For AC Solar
 - Select Micro Inv Input
 - ON 90%
 - OFF 95%
- To save the settings, press the checkmark



NEOVOLTA™

LCD Settings


- Select the gear icon
- Select Basic Setting



NEOVOLTA™

LCD Settings

- This page is the same configuration for single or parallel inverters.
- Program the date and time.
- Please ensure Beep is de-selected.
- Please ensure Auto Dim is selected.
- To save the settings, press the checkmark



NEOVOLTA™

LCD Settings

- To program parallel inverters
- Select Advanced Function



NEOVOLTA™

LCD Settings

- For Parallel Configurations,
- Program parallel on the slave inverter first.
- Select the gear icon, select Advanced Function
- Select Parallel, Slave, Modbus SN 02, A Phase
- To save the settings, press the checkmark



NEOVOLTA™

LCD Settings

- For Parallel Configurations,
- Program parallel on the master inverter.
- Select the gear icon, select Advanced Function
- Select Parallel, Master, Modbus SN 01, A Phase
- To save the settings, press the checkmark



NEOVOLTA™

Parallel Systems Configuration

1. Turn off the slave first.
2. Turn off the master next.

After 5 minutes:

- Restart slave first then the master.
- The inverter should show Green LED, normal.

If normal doesn't come on, it means there are 0 V on the load.

Verify the slave has the same parameters from the master.

- For example, check to see if the slave inverter has the same settings as the Master.
- Gear icon->Battery Settings-> First page (Batt Mode)
- Max A Charge 185A
- Max A Discharge 185A

It's a good way to check the parallel system is working.

Then turn on solar, verify all is functional, with the grid off.

Once that has successfully been configured, turn the grid on.

NEOVOLTA™

Prior to commissioning:

1. Please obtain the WiFi information for the plant.
2. The email address that will be used for commissioning.
 - a. If the homeowner's email will be used, please note a verification code will be sent to the email address when the account is registered.
 - b. The account can be created prior to going onsite. This allows for requesting the verification code from the homeowner ahead of time.

NEOVOLTA™

Selecting the Correct Solarman App

**Both homeowner and installer require an account.
They are created in different apps.**

- Solarman Smart – Homeowner
- Solarman Business – Installer
- Solarman Pro – Europe/Non-U.S.

The system should be commissioned using the system owner's account.

NEOVOLTA™

Selecting the Correct Solarman App

Determining the owner of the system

The owner would be classified as:


- **The homeowner purchased the system -> Use Solarman SMART.**
- **The installer purchased the system and is leasing the system to the homeowner -> Use Solarman Business.**
- **Third party, such as HDM, San Diego Community Power, etc. -> this is at the discretion of the third party/installer/homeowner. NeoVolta has primarily seen it commissioned through the installer's account through Solarman Business. Commissioning through the installer's account allows the installer to manage the system if there's a change to WiFi, etc.**

NEOVOLTA™

App Store

Search Solarman

- **Solarman Smart** - Homeowner
- Solarman Business - Installer
- Solarman Pro - Europe/Non-U.S.



NEOVOLTA™

Commission Using Solarman Smart


- Solarman Smart –
Homeowner



NEOVOLTA™

Choose region


- Select your region



NEOVOLTA™

Service Agreement and Privacy Policy


- Please read
- Once you have read,
- Select the blue 'Agree' button



NEOVOLTA™

Solarman SMART


- App will request to use location
- Accept 'Allow While Using App'
- This will help find the install address faster



NEOVOLTA[™]

Solarman SMART


- Register with Email on the App
- Select Next



NEOVOLTA[™]

Solarman SMART


- A Verification Code will be sent the email provided
- Enter the Verification Code



NEOVOLTATM

Solarman SMART


- Set a password
- Select Register



NEOVOLTA™

Solarman SMART


- A Register successfully! Prompt should appear.
- Select Add



NEOVOLTA[™]

Solarman SMART


- Answer the prompts and select Next



NEOVOLTA[™]

Solarman SMART


- Answer the prompts and select Next



NEOVOLTA[™]

Solarman SMART


- Answer the prompts and select Done



NEOVOLTA[™]

Solarman SMART


- The Plant has been created
- Select Start



NEOVOLTA[™]

Solarman SMART


- Add Data Logger
- Scan the QR Code



NEOVOLTA™

Solarman SMART


- Grant Access based on preference



NEOVOLTA[™]

Solarman SMART


- Connect to the Homeowner's WiFi



NEOVOLTA™

Solarman SMART


- It will open the cell phone WiFi settings.
- Connect to the homeowner's WiFi settings.
- Return to the Solarman SMART app.



NEOVOLTA™

Solarman SMART


- The app will request connecting to the DataLogger.
- Select Connect.



NEOVOLTA™

Solarman SMART


- Open the Cell Phone WiFi settings.
- Select the AP_loggerserialnumber.
- Enter password, if it was not scanned with QR Code.
- It will connect and my provide the message "Connected without internet"
- Return to the Solarman SMART app.



NEOVOLTA[™]

Solarman SMART


- The app should start automatically connecting.



NEOVOLTA[™]

Solarman SMART


- Once complete, the inverter and logger should be visible on the plant.



NEOVOLTA™

Create a Plant


- After it has successfully connected, please return to the cellphone settings and change the WiFi from the logger.



NEOVOLTATM

Solarman SMART


- Add slave device, by selecting “+”
- Select “Add Device”



NEOVOLTA[™]

Solarman SMART

- It will prompt to add Data Logger
- Scan the QR Code
- Repeat the same steps



NEOVOLTA™

Solarman Smart

Settings for Parallel Inverters


Label as Primary (Master)
and Secondary (Slave)
accordingly

	Inverter	Logger	
	Name/SN		Status
<input type="checkbox"/>	Master		
	2409286296		
<input type="checkbox"/>	Slave		
	2409286293		

NEOVOLTATM

Solarman SMART


- Authorize NeoVolta and Installer
- Select Sharing



NEOVOLTA™

Solarman SMART


- Select Share with merchants



NEOVOLTA™

Solarman SMART


- Select Administrator



NEOVOLTA™

Solarman SMART


- Enter NeoVolta in the search box
- Click the add icon
- Select Search



NEOVOLTA[™]

Solarman SMART


- The prompt “Added successfully” will appear.
- Select OK.



NEOVOLTATM

Solarman SMART


- Add the installer.
- Select “+” next to Share with merchants.



NEOVOLTA™

Solarman SMART


- Select Member.
- Select Confirm.



NEOVOLTATM

Solarman SMART


- Search for the installer.
- Click the add icon
- Select Search



NEOVOLTA™

Solarman SMART


- The homeowner will be listed as the owner of the plant.
- NeoVolta and the installer have been granted access to remotely monitor the plant.



NEOVOLTA™

Solarman SMART


- If additional business third parties need to be added, for example, HDM, San Diego Community Power, etc.
- Select “+” next to Share with merchants.



NEOVOLTA™

Solarman SMART

- Select Member.
- Select Confirm.



NEOVOLTATM

Solarman SMART

- Search for the third party business.
- Click the add icon
- Select Search




NEOVOLTA™

Complete

Dashboard


- 1 Plant now displays



NEOVOLTA™

Commission Using Solarman Business


- Solarman Business –
Installer



NEOVOLTA™

Service Agreement and Privacy Policy


- Please read
- Once you have read,
select the blue 'Agree'
button



NEOVOLTA™

Solarman Business App


- App will request to you use your location
- Grant access based on preference.
- This will help find the install address faster.



NEOVOLTA™

Solarman Business


- App will request to 'Allow Bluetooth' with Solarman
- You can select either, but we do not use this feature



NEOVOLTA™

Solarman Business App


- App will request to send you notifications
- Select 'Allow'
- This will notify you when the system is under going maintenance



NEOVOLTA™

Choose Region


- Select your region



NEOVOLTA™

Dashboard

- Overview of plants
 - Incomplete
 - Offline
 - Partially Offline
 - Alerts




NEOVOLTA™

Creating your plant

Plus Sign in the top right corner

- Click the plus sign
- Tap 'Create a Plant'




NEOVOLTA™

Create a Plant

First Step

- Change cover photo




NEOVOLTA™

Add photo of home

Cover Section


- Select the default photo
- App will ask you to 'Take Photo'



NEOVOLTA™

Permissions

- Grant Access based on preference.



NEOVOLTA™


Plant Settings

Capacity

- Manually enter the system size in kW

System Type

- PV + Grid + Consumption + Battery




NEOVOLTA™

Plant Type

Pick the plant type


- Residential
- Commercial
- Industrial
- Ground
Mounted



NEOVOLTA™

Time Zone


Select the 'More' option



NEOVOLTA™

Time Zone

Tap Time
Zone




NEOVOLTA™

Time Zone

Find and select the correct time zone

- Important for 'Time of Use' and other settings




NEOVOLTA™

Contact Person

Please add in the information for the homeowner owner.


Add their Name and Best Contact Number.



NEOVOLTA™

Create a Plant


- Connect to the homeowner's WiFi on your cell phone settings



NEOVOLTA™

Create a Plant

- Add Datalogger



NEOVOLTA™

Create a Plant


- Scan QR Code
- If that does not work, you can manually enter the password



NEOVOLTA™

Create a Plant


- To manually connect, connect to the homeowner's WiFi in the Solarman Business App



NEOVOLTA™

Create a Plant



- You will see the following screens
- Select Connect



NEOVOLTA™

Create a Plant


- It will open the phone's WiFi settings
- Select the WiFi with the AP_LoggerSerialNumber



NEOVOLTA™

Create a Plant


- Enter the password listed on the Logger. It is listed as PWD.



NEOVOLTA™

Create a Plant


- The cellphone WiFi will connect to the logger. Please note it may display no internet connection message.



NEOVOLTA™

Create a Plant


- Return to the Solarman Business App. It will go through the Device Configuration settings.



NEOVOLTA™

Create a Plant

- Once it has completed, it will display Configuration Succeeded.






NEOVOLTA™

Create a Plant


- After it has successfully connected, please return to the cellphone settings and change the WiFi from the logger.



NEOVOLTA™

Plant


- Plant main page
- Top right hand of screen to add NeoVolta



NEOVOLTA™

Authorize NeoVolta

Authorize
Plant




NEOVOLTA™

Authorize Plant

Business

+ Click here to authorize business
units




NEOVOLTA™

Authorize Plant

If additional business third parties need to be added, for example, HDM, San Diego Community Power, etc.

+ Click here to authorize business units




NEOVOLTA™

Adding NeoVolta

Bottom of the screen

- In small print
- Select the blue 'Click here'




NEOVOLTA™

Adding NeoVolta

Search Bar

- Type out NeoVolta
- Select 'Search'
- When the NeoVolta name shows up, tap to select




NEOVOLTA™

Authorize Plant

End-user


+ Click here to authorize end
users



NEOVOLTA™

Authorize End User


- Tap 'Authorize End User'
- Follow prompts to enter homeowner email address and create a temporary password
- Double check email and password before continuing
- Provide both to homeowner and have them download Solarman **Smart**
- If there are any login issues, they can select "forgot password" and it will have them create a new one



NEOVOLTA™

Me


Can view your company
Make changes to Settings



NEOVOLTA™

Settings


Edit the Temperature
Preference
Select Preference



NEOVOLTA™

Tempature

- Select Celsius or Fahrenheit




NEOVOLTA™

Complete

Dashboard

- 1 Plant now displays



NEOVOLTA™

Solarman Business Settings


If the inverters are not programmed on the LCD screen, they can be programmed remotely.

NEOVOLTA™

Solarman Business

Settings for Parallel Inverters

Add both inverters on the same plant



NEOVOLTA™

Solarman Business

Settings for Parallel Inverters

Label as Primary (Master)
and Secondary (Slave)
accordingly

Inverter	Logger	Status
Name/SN		
<input type="checkbox"/> Master	2409286296	
<input type="checkbox"/> Slave	2409286293	

NEOVOLTA™

Solarmen Business Settings

Select Edit

0000 NeoVolta LAB ID671315 Offline No Alerts

Experience All New Dashboard

Edit Tags

Last update 2025/05/07 09:44:59 UTC-07:00

Flow Graph Production Consumption Grid Battery

Solar Power: -- Capacity: 0.01 kWp

Grid --

Microinverter --

Battery --

Consumption --

Address 13651 Danielson Street, San Jose, CA 95131

Plant Type Residential

System Type PV + Grid + Consumption

Phone 8582659347

Cover



Updated: 2025/05/11 14:00:00

69°F

59°F/84.2°F Cloudy SUN

4.5 m/s 05:53 19:37

69.8°F 64.4°F 62.6°F 62.6°F

59°F 60.8°F 59°F 59°F

MON TUE WED THU

5/12 5/13 5/14 5/15

Cloudy Sun icon

Wind speed: 4.5 m/s

Wind direction: 05:53

Sunrise: 19:37

Temperature forecast for the next four days: 69.8°F, 64.4°F, 62.6°F, 62.6°F

Humidity forecast for the next four days: 59°F, 60.8°F, 59°F, 59°F

MON TUE WED THU

5/12 5/13 5/14 5/15

NEOVOLTA™

Solarman Business Settings

1. Under Plant Info

2. Select the correct Time Zone

3. Select System Type:

- PV + Grid + Consumption + Battery

4. Add the Owner Info

5. Select Done

Time Zone :

(UTC-07:00) Pacific Time (US & Canada)

System Type : [?](#)

PV + Grid + Consumption + Battery

Owner Info

Contact Person :

Phone :


Business Name :

[Collapse ^](#)

NEOVOLTA™

Solarman Business Settings

Select the inverter and select Device Control



Master:2409286296

Online

2025/04

Details Alert Architecture Historical Data

Basic Information

SN: 2409286296	Inverter Type: Single phase LV Hybrid	General settings: 0,1,3,4,5,7,9,10,11,13,14,15
Battery Voltage Type: LV-48V	IMEI:	Rated Power: 8 kW

NEOVOLTA™

Solarman Business Settings for Parallel Inverters

On the slave inverter only program Advanced Function – 1 inverter. Program the slave inverters prior to the master.

Batch Command Single Command Customized Command Control Log Export Results

Advanced Function-1

The current command group must be configured as a whole

* ARC Setup	* Gen peak-shaving	* Gen peak-shaving power	* Grid peak-shaving	* Grid peak-shaving power
OFF	Disable	8000 W	Disable	8000 W
* Backup Delay	* parallel	* Equipment mode	* Modbus SN	* Phase
0 ms	Enable	Slave	2	A Phase
* Auto Detect Home Limit Sensors	* DRM	* Signal Island Mode	* BMS-stop	* CT ratio
Please Select	Disable	Disable	Disable	2000 : 1
* EX_MeterCT	* Meter Select	* Grid Tie Meter2	* ATS Enable	* Low Power Mode
Disable	No Meter	Disable	ATS Disable, Status OFF	Disable
Advanced Function-2	* Low Noise Mode	* MPPT Multi-Point Scanning		
	Please Select	Disable		

NEOVOLTA™

Solarman Business Settings for Parallel Inverters

Program the master inverter with all the values. Program the master Advanced Function-1 last.

Batch Command Single Command Customized Command Control Log Export Results

Advanced Function-1 The current command group must be configured as a whole

Battery Setting-1	* ARC Setup	* Gen peak-shaving	* Gen peak-shaving power	* Grid peak-shaving	* Grid peak-shaving power
Battery Setting-2	OFF	Disable	8000 W	Disable	8000 W
Battery Setting-3	* Backup Delay	* parallel	* Equipment mode	* Modbus SN	* Phase
System Work Mode-1	0 ms	Enable	Master	1	A Phase
System Work Mode-2	* Auto Detect Home Limit Sensors	* DRIVI	* Signal Island mode	* BMIS-stop	* CT Ratio
Grid settings	Please Select	Disable	Disable	Disable	2000 : 1
SmartLoad	* EX_MeterCT	* Meter Select	* Grid Tie Meter2	* ATS Enable	* Low Power Mode
Basic Setting	Disable	No Meter	Disable	ATS Disable, Status OFF	Disable
Advanced Function-1	* Low Noise Mode	* MPPT Multi-Point Scanning	Disable		
Advanced Function-2	Please Select	Disable			

NEOVOLTA™

Solarman Business Settings for Parallel Inverters

- Continue with subsequent slides to program the master inverter.

NEOVOLTA™

Battery Setting - 1

Batch Command Single Command Customized Command Control Log Export Results

☰ **Battery Setting-1** ⓘ The current command group must be configured as a whole

Battery Setting-1	* Batt Type	* Battery Capacity	* Batt Empty V	* Batt Resistance	* Batt Charge Efficiency
Battery Setting-2	BMS Lithium Batt	200 Ah	45.00 V	8 mΩ	99.0 %
Battery Setting-3					
System Work Mode-1					
System Work Mode-2					
Grid settings					
SmartLoad					
Basic Setting					
Advanced Function-1					
Advanced Function-2					

NEOVOLTA™

Battery Setting - 2

Batch Command Single Command Customized Command Control Log Search command item Export Results

Battery Setting-2

The current command group must be configured as a whole

* Max A Charge	* Max A Discharge	* Batt Shutdown %	* Batt Restart %	* Batt Low %
185	185	10	22	20
* Activate Battery	* Lithium Mode	* Disable float charge		
Enable	0	Disable		

Lithium Mode 0 for NVPlus
Lithium Mode 1 for NV14

Charge and discharge amps ONLY for PCS.

Max A Charge = 185A
Max A Discharge = 185A

Single inverters
Max A Charge= 100A
Max A Discharge = 150A

NEOVOLTA™

Battery Setting -3

Batch Command Single Command Customized Command Control Log Search command item Export Results

Battery Setting-3 i The current command group must be configured as a whole

Battery Setting-1	* Grid Charge	* Gen Charge	* Grid Signal	* Gen Signal	* Grid Start %
Battery Setting-2	Enable	Disable	Enable	Disable	20 %
Battery Setting-3	<hr/>	<hr/>	<hr/>	<hr/>	
System Work Mode-1	* Grid Charge Ampere	* Gen Force			
System Work Mode-2	185 A	Disable			

ONLY for PCS:
Grid Charge Ampere = 185A

Only for Single inverters:
If no grid charge, Grid Charge Ampere =10A
If grid charge, Grid Charge Ampere = 75A

- Battery Setting-1
- Battery Setting-2
- Battery Setting-3**
- System Work Mode-1
- System Work Mode-2
- Grid settings
- SmartLoad
- Basic Setting
- Advanced Function-1
- Advanced Function-2

NEOVOLTA™

System Work Mode-1

Batch Command Single Command Customized Command Control Log Export Results

System Work Mode-1

The current command group must be configured as a whole

*** System Work Mode**

Zero Export to Load

Grid Selling First

Zero Export to Load

Zero Export to CT

*** Solar Sell**

Disable

*** Setup**

Monday Tuesday

Wednesday Thursday

Friday Saturday

Sunday

*** Max Sell Power**

8000 W

*** Max Solar Power**

9000

System Work Mode:

NO CTs - set to Zero Export to Load

CTs- set to Zero Export to CT

NEOVOLTA™

System Work Mode-1

Batch Command Single Command Customized Command Control Log Search command item Export Results

System Work Mode-1

The current command group must be configured as a whole

Battery Setting-1

* System Work Mode: Zero Export to Load

* Solar Sell: Disable

* Setup: Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, Sunday

* Max Sell Power: 8000 W

* Max Solar Power: 9000

System Work Mode-1

* Energy Pattern: Batt First

* Zero export power: 20

System Work Mode-2

Grid settings

SmartLoad

Basic Setting

Advanced Function-1

Advanced Function-2

Energy Pattern:

- **Load First**

Batt First: PV power is firstly used to charge the battery and then used to power the load. If PV power is insufficient, grid will make supplement for battery and load simultaneously.

Load First: PV power is firstly used to power the load and then used to charge the battery. If PV power is insufficient, grid will make supplement for battery and load simultaneously.

NEOVOLTA™

System Work Mode-1

Batch Command Single Command Customized Command Control Log Search command item Export Results

System Work Mode-1

*** System Work Mode** Zero Export to CT

*** Solar Sell** Enable Setup

Monday Tuesday
 Wednesday Thursday
 Friday Saturday
 Sunday

*** Max Sell Power** 8500 W

*** Max Solar Power** 8500

The current command group must be configured as a whole

*** Energy Pattern** Load First

*** Zero export power** 20

Solar Sell:
Enable
Either all days deselected or have all the days selected

Battery Setting-1
Battery Setting-2
Battery Setting-3
System Work Mode-1
System Work Mode-2
Grid settings
SmartLoad
Basic Setting
Advanced Function-1
Advanced Function-2

NEOVOLTA™

System Work Mode-2

Batch Command Single Command Customized Command Control Log Search command item Export Results

System Work Mode-2 The current command group must be configured as a whole

* Time of Use

ON


Time	Grid Charge	Gen	Start Time	End Time	Power	Batt
Time 1	ON	OFF	01:00	05:00	8000 W	30 %
Time 2	ON	OFF	05:00	08:00	8000 W	30 %
Time 3	OFF	OFF	08:00	12:00	8000 W	100 %
Time 4	OFF	OFF	12:00	16:00	8000 W	100 %
Time 5	ON	OFF	16:00	21:00	8000 W	30 %
Time 6	ON	OFF	21:00	01:00	8000 W	30 %

Battery Setting-1
Battery Setting-2
Battery Setting-3
System Work Mode-1
System Work Mode-2
Grid settings
SmartLoad
Basic Setting
Advanced Function-1
Advanced Function-2

NEOVOLTA™

Grid Settings

Enter 7777



NEOVOLTA™

Grid Setting - Basic

Grid Setting-Basic

① The current command group must be configured as a whole

* Grid Mode	* PF	* Grid Frequency	* Grid Type	* Inverter output voltage
<input type="text" value="CPUC RULE21"/>	<input type="text" value="1.000"/>	<input type="text" value="60Hz"/>	<input type="text" value="120/240V Split Phase"/>	<input type="text" value="120/240V"/>
* import power limiter	* Export power limiter			
<input type="text" value="10350"/>	<input type="text" value="8000"/>			

Battery Setting-1

Battery Setting-2

Battery Setting-3

System Work Mode-1

System Work Mode-2

Grid Setting-Basic

Grid Setting-Connect

Grid Setting-IP Protection

Grid Setting-F(W)

Grid Setting-V(W)V(Q)

Grid Setting-P(Q)P(F)

SmartLoad

Basic Setting

Advanced Function-1

Advanced Function-2

NEOVOLTA™

Basic Setting

Batch Command Single Command Customized Command Control Log Export Results

Basic Setting

! The current command group must be configured as a whole

Battery Setting-1	* AM/PM Disable	* Auto Dim Enable	* System Time 2025-06-29 07:40:51	* Factory Reset Disable	* Time Syncs Enable
Battery Setting-2					
Battery Setting-3					
System Work Mode-1	* BEEP Disable	* lock out all changes Disable			
System Work Mode-2					
Grid settings					
SmartLoad					

Auto Dim – Enable.
BEEP – Disable.

NEOVOLTA™

Solarman Business Settings for Parallel Inverters

- Verify the slave has the same parameters from the master.
- For example, check to see if the slave inverter has the same settings as the Master.
- Select Battery Setting-2
 - Max A Charge 185A
 - Max A Discharge 185A